


NL MONTAGEVOORSCHRIFT

D MONTAGE-ANLEITUNG

F MOUNTING INSTRUCTIONS

E INSTRUCTIONS DE MONTAGE

# AGAVE HR-EL



L	H	Watt
500	1322	750
500	1874	1000
600	1874	1250

